

VanAmps *Pedal Deck*

INSTALLATION INSTRUCTIONS

PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY FOR PROPER OPERATION OF THE PEDAL DECK.

THE PEDAL DECK CAN BE INSTALLED ON BOTH THE REVERBAMATE AND SOLE-MATE REVERB PEDALS.

1. REMOVE THE SIX PHILIPS HEAD SCREWS ON THE BOTTOM OF THE REVERB PEDAL AND PLACE THE COVER ASIDE.
2. LOCATE THE TWO FORWARD PHILIPS HEAD SCREWS ON THE TOP OF THE REVERB PEDAL AS SHOWN IN THE ILLUSTRATION BELOW. LOOSEN THE TWO SCREWS WITH A PHILIPS SCREW DRIVER BY HOLDING THE INSIDE NUT WITH A 1 1/32" TOOL. THIS IS BEST ACCOMPLISHED BY PUTTING THE UNIT ON IT'S END (THE END OPPOSITE THE POWER JACK FOR BETTER STABILITY) AND WORKING ON THE UNIT WITH BOTH HANDS. ONCE BOTH SCREWS ARE BACKED OFF, PRY THE FINISHING WASHER FROM THE COVERING IF THEY ARE NOT LOOSE.
3. HOLDING THE REVERB PEDAL UPSIDE DOWN ABOVE THE WORK SURFACE, SLIDE THE HINGE OF THE PEDAL DECK BETWEEN THE FINISHING WASHERS AND THE MOUNTING SURFACE OF THE UNIT SO THAT THE SLOTS LINE UP WITH THE LOOSENED SCREWS. ONCE THIS IS ACCOMPLISHED, SET THE REVERB PEDAL ON THE WORK SURFACE AND COLLAPSE THE PEDAL DECK TO THE DOWN POSITION AND MAKE SURE THERE IS CLEARANCE ON BOTH SIDES OF THE DECK SO THAT THE DECK DOES NOT RUB ON THE REVERB COVERING. AT THIS POINT HOLD THE PEDAL DECK IN PLACE AND TIGHTEN THE SCREWS WHILE AGAIN HOLDING THE NUTS.

***NOTE:** WHEN USING THE PEDAL DECK, INSURE THAT THE HINGED SUPPORT IS IN IT'S FULLY UPRIGHT POSITION TO PREVENT ACCIDENTAL COLLAPSE DURING USE.

TOP VIEW

